

## SC35 SERIES LANTERN

### QUICK START GUIDE

SC35 lantern combines a LED light source, a power unit (battery) and solar panels in one single weather-protected unit.

SC35 series lanterns are designed to have minimal interaction to the general users.

#### PACKAGE CONTENTS:



1 x SC35 Beacon (Lantern)  
(Actual product might be slightly different)



1 x IR Remote Control Device

#### ACTIVATION PROCEDURE:

1. Remove the beacon and remote-control device from packaging.
2. Point the remote-control device at the lantern dome, press and hold "\*" (star) button for 2 seconds, then press 1121, this command will take the lantern out of Sleep Mode.
3. Release the button. The beacon should be on for a second to acknowledge the command.
4. The beacon should be flashing your requested flash setting  
If not please refer to the Flash Setting Sheet and program your desired code.
5. To place the beacon in sleep mode press and hold "\*" (star) button for 2 seconds, then press 1120.
6. For other settings, refer to the manual.

**Note:** Activation during daytime, the beacon's dome (lens) might need to be covered to simulate night time for proper operation.